


Smart Mini Reader

Getting started



Get to know your reader



Getting started

1 Charge your Smart Mini reader

Connect the provided USB cable to the charging port.

Note: you can continue setting up your reader whilst it's charging.

2 Download the app

Using the Google Play™ or Apple App Store on your phone/tablet, search **Smart Mini** to download the Smart Mini app.



3 **First time log in**

In the Smart Mini app, enter your user ID and temporary PIN which you would have received via email. Follow the prompts to request an activation code to reset your PIN for future logins.

4 **Pair the Smart Mini reader to your device**

Ensure Bluetooth is turned on on your phone/tablet. Turn your reader on by pressing the **On** button for two seconds. Select **Connect reader** on the Smart Mini app home screen. Scan the serial number located on the back of your reader.

Taking payments

Select **Take payment** on the Smart Mini app home screen and follow the prompts until a payment amount has been confirmed.

Tap

Instruct the customer to tap their card on the payment reader. A successful tap will sound a 'beep'.

Insert

Instruct the customer to insert their chip card into the reader and enter their PIN on your phone/tablet.

Support

For full user guide and security tips,
visit our merchant support hub on
commbank.com.au/merchantsupport

For further support, please call the CommBank
Merchant Helpdesk on **1800 230 177**.

Warranty

CommBank provides a limited
warranty for your Smart Mini reader.
For details on warranty and claims, visit
commbank.com.au/smart-mini-warranty

Apple and Apple App Store are trademarks of Apple Inc.,
registered in the U.S. and other countries and regions.
Google, Google Play and related marks and logos are trademarks
of Google LLC.

ABN 48 123 123 124 AFSL 234945

CBA5225 010123